

## C3-2500

## C3-100



### Standard Display



### Trouble Code



- 1) Trouble Code #
- 2) Occurrence Count
- 3) Text Message
- 4) Yellow LED (Pre Alarm)
- 5) Red LED (Alarm)

### Throttle Down



### Throttle Up



Arrows indicate increase or decrease.